


Removing the light unit




Easily removable to recharge light or wash hat.

Recharging the light unit



Remove the USB cover and plug into any USB socket found on phone adaptor, computer etc.

The charging light will illuminate red while charging and turn green when charged.



- Long Press for Red: High/Flashing
- Press switch again to turn off

Brightness Memory Function

Previous brightness level will be memorised and resume when turned on.













WIDE BEAM

RED BEAM